

MHR STRAIGHT PCB MOUNT

A = .100 [2.54] x No. of Spaces + .860 [21.84]
 B = .100 [2.54] x No. of Spaces + .460 [11.68]
 C = .100 [2.54] x No. of Spaces

MHR-26-VUAL

Latch Options

Header with Short Ejector/Latch for Sockets without Strain Reliefs

Header with Long Ejector/Latch for Sockets with Strain Reliefs

MHR RIGHT ANGLE PCB MOUNT

A = .100 [2.54] x No. of Spaces + .860 [21.84]
 B = .100 [2.54] x No. of Spaces + .460 [11.68]
 C = .100 [2.54] x No. of Spaces

MHR-26-HUAL

Recommended PCB Layout